	Connection	P1C1	16	32	Poly	p1	p2	p3	p4	p5	p6	p7
Emagic Unitor 8 MK II	Serial Fast	0.6><3	0,8><5,2	1,8><6	5,6><10,8	1><4,4	2><5.2	2.2><5.6	3.8><6.6	3.8><6.6	4><7	4.6><8.2
Emagic Unitor 8 MK II	USB	0,2><2,6	1><5	1,8><6,6	5,6><9,6	1><4,6	1.8><6.8	2><6.8	2.6><8	3.8><8	3.8><8.6	4><9
Emagic amt8	Serial Fast	0,8><3,6	1><5,2	2,2><5,2	4,4><5	1,2><4,7	2><4.7	3.2><5	3.2><5	4><6	4><7.8	5><7.8
Emagic amt8	USB	0,2><2,9	0.8><5.8	1,8><6.2	5.6><10.8	0,8><3,8	1.4><6	2.2><6.6	2.8><7.2	3.2><8	3.6><8.2	4.2><9
Midiman Midisport 8x8	Serial	0.8><4	1.4><4.6	1.6><5.6	6><8.8	1.4><4	2.2><5.2	2.6><5.6	3.2><6.4	3.6><6.8	4><6.8	4.6><7.6
Midiman Midisport 8x8	USB	0.4><3.4	0.4><5	3.4><9.6	12><22	0.4><3.6	0.8><4.2	0.8><4.6	0.8><4.4	0.8><4.4	1><4.4	1><4.6
Motu Midi Express XT USB	Serial 1MHz	0,8><6,2	3,2><7,2	5,4><10,8	8,8><12,6 (C48)	3,8><7,2	4.8><9.8	7,4><10,8	8,8><12	10><13,2	11,6><16	14.8><18
Motu Midi Express XT USB	USB	4><7,4	4,2><7,4	4,4><7,4	4,4><8	4,4><9,2	4,8><9,2	5,4><9,2	6><9,8	8><10	8,2><9,8	8,8><10,8
Motu Midi Express XT	Serial 1MHz	1,6><5,8	3><7,2	5,2><11,2	5,2><11,2 (C48)	3,8><7,8	5,6><10	7,2><12,2	9,2><14	10,8><15,6	12,4><16,4	15,2><18,6
Motu MTP AV	Serial Fast	0,8><5,2	1,2><5,8	2><6,6	6><9,2	1,4><5,4	1,8><6	2.8><7,4	3,2><7,8	3,6><8	3,8><8,2	4,2><8,8
Motu MTP AV	Serial 1MHz	1,8><5,2	4,4><8,6	6><9,8	10,8><14,2 (48)	3,4><8	7.6><10.2	7.6><12.4	9.2><14	12.4><15.6	13.6><16.4	13.6><18
Motu MTP AV	USB	3,2><7,8	3,8><8,2	4,2><8,6	7><10	4,2><8,4	4.8><9.8	4.8><10.4	5.6><10.8	6><11.2	6.4><11.2	6.8><11.8
Motu Micro Express	Serial 1MHz	1.6><5.8	3.2><7.4	5><8.2	10.4><14.4 (C65)	4.2><7.6	5.6><8.4	7.4><10.4	8.8><12.2	10.4><13.6		
Motu Micro Express	USB	3,2><7.8	4.2><8.2	4.6><10.2	5.6><12.4	3.8><6.8	4.8><7.2	5.2><8	5.8><8.4	6.2><9.2		
Yamaha UX-256	USB	0.8><3.2	2.8><5.6	5.6><8.2	14.4><18	1><3.4	1.2><4	1.6><4	1.8><4.2			
Emagic mt4	USB	0.2><4.8	1.2><5.2	1.2><6.4	1.8><5.2	0.8><5.8	1.2><5.2	1.4><5.2				
Midiman Midisport 4x4	USB	0.8><3.8	1.6><4.8	1.6><6.4	3><6.2	0.8><4.2	1><5.2	1><4.6				
RolandED UM-4	USB	0.6><4.8	1.8><5.2	3.2><7.8	4.2><10.4	1.6><5.8	2.2><6.6	3.2><8				
Midiman Midisport 2x2	USB	0.6><3	1.2><4.6		1.2><4.6	0.8><3.6						
Motu FastLane USB	USB	3><7,2	3.6><7.8			3,8><8						
Motu Pocket Express	Serial 1MHz	0.4><3.2										
Steinberg USB-2-MIDI	USB	0.4><4,2	0,8><5,4			0,4><5,2						
RolandED UM-2	USB	0.4><4.8	2><6.8			1.4><6.4						
Midiman Midisport 1x1	USB	0.6><3.6										
RolandED UM-1	USB	0.4><3.4										
Dumb Interface	Serial 1MHz	1.4><4.8										